

1. Take out the base cabinet by pulling the carrying belts, and lay it on a matted floor gently (Fig. 1). Unbuckle the carrying belts and pull down the protective fabric to install the 4 spikes from the small white box (Fig. 2 & 3).
2. Remove the protective fabric and rotate (don't use the rear spikes as the pivot points; instead, lift the cabinet and rotate it) the base cabinet to the upright position (spikes against floor) and place it to the listening position. Repeat steps 1 and 2 for the other channel (Fig. 4).
3. Place the 3 disks from the white box on top of the base cabinet in positions (2 at front and 1 at back) (Fig. 5).
4. Take out the top cabinet, and gently place it on a matted floor. Remove the protective fabric and carrying belt (Fig 6, 7 & 8).
5. Install the long angle adjusting screw for the top cabinet and turn the screw until the tip of the screw passes the bottom of the supporting arm of the top cabinet about 1/2 inch (Fig. 9).
6. Place the top cabinet carefully on top of the 3 disks placed on the top of the base cabinet earlier in step 3 (Fig. 10). Repeat the steps 5 and 6 for the other channel.
7. Adjusting the final position for the top cabin, and Install the jumper for single wire speaker cable (Fig. 11). Jumpers are not needed for bi-wire setup (Hyperion default setup).

